


Potable & Salt Water Diagram

HIN: OEX370630887



- Fresh water
- Sea water
- Heated engine water to augment hot water
- Air vent and filler lines
- Hot fresh water

Notes:

- 1 - ShurFlow pump on DC breaker "Pressure Water"
- 2 - 50 psi Par-Max4 on DC breaker "Salt Water Wash Down"
- 3 - Water level is read on the pilot house instrument panel